

**FOR TRACK LONGER THAN 70"**

1. Assemble same as above, replacing 1" Omega spacer at control end with one rod support carrier at the right of carrier train.

**CORDING**

1. Take near cord through gear end, through middle hole of rod support carrier, then through bottom hole of lead carrier and tie off.
2. Install far cord same as above.

**BEADING**

1. Stack carriers toward idle end and center rod support carrier on exposed tilt rod.
2. Place a cord bead on the near cord on the right side of the rod support carrier.

**FOR TRACK LONGER THAN 200"**

1. Assemble with two rod support carriers as for regular side draw over 200" but in reverse order (see page 10).
2. Cord and bead same as regular side draw over 200" as shown on page 10.